CRYSTORAMA

LIGHTING THE WAY FOR SIXTY YEARS

ASSEMBLY INSTRUCTION MODEL #ROY-801-GA

Crystorama.com

59 3/4"

14"

7"

HOW TO INSTALL:

Place the fixture parts on a soft cloth-covered platform before installation of fixture.

1. Install the bulb(not included) into the socket.
   Screw the threaded pipe into the bottom of the harp and secure with hex nut.
   Place the glass shade over the bottom of threaded pipe.
   Secure with the plastic washer and finial.

2. Decide the preferred hanging height and choose the correct number of rods needed.

3. Feed the fixture wires through the rods and canopy.Screws the rods together.
   Screw one end of the rod assembly onto the top of metal frame and the other end onto the swivel on the canopy.

4. Install the mounting plate onto the outlet box and raise the fixture up to the ceiling.
   After the wire connection is complete, secure the canopy onto the mounting plate using screws.

CRYST☉RAMA

LIGHTING THE WAY FOR SIXTY YEARS

Crystorama.com

ASSEMBLY INSTRUCTION MODEL #ROY-801-GA

Outlet Box

A

D

B

C

Part Number

Part Numbers

A. (1)-Mounting hardware
   Wire connector x2.
   Mounting plate x1.
   Mounting screw x2.

B. (2)-Canopy screw

C. (1)-Swivel

D. (1)-Canopy(W5 1/8"xH1") ; with 2 side holes.
   -XSN801GACAN5.125IN

E. (1)-H6" Rod ; Ø15.8mm-XSN801GAROD6IN

F. (3)-H12" Rod ; Ø15.8mm-XSN801GAROD12IN

G. (1)-Metal frame ; W6 7/8" x H14"

H. (1)-Nut

I. (1)-Threaded pipe ; H3"

J. (1)-Glass shade ; W6 1/2" xH13 5/8"
   XSN801SHA13.625IN

K. (1)-Plastic washer

L. (1)-Finial-XSN800GAFIN

E

G

Harp

F

H

I

J

K

L